


RE 29293

Edition: 2022-05 Replaces: 2019-06



Directional control valve, pilot-operated, with integrated field bus (IFB-Multi-Ethernet)

Type 4WRLF



- ▶ Sizes 10 ... 27
- ► Component series 4X
- ► Maximum operating pressure of 350 bar (ports P, A, B)
- ► Rated flow 600 l/min (**Δp** = 10 bar)



Features

- Integrated fieldbus (IFB Multi-Ethernet)
- Bus connection/service interface (Sercos, EtherCAT, EtherNet/IP, PROFINET RT, VARAN)
- ► Scalable
 - 2 configurable analog pressure sensor inputs
- ▶ Precise
 - Integrated pressure/force control, optional
 - High response sensitivity and low hysteresis
- ▶ Safe
 - Internal safety function (can be used up to category 4/PL e according to EN 13849-1)
 - CE conformity according to EMC Directive 2014/30/EU

Contents

Features	1
Ordering code	2, 3
Symbols	4
Function	5, 6
Pilot oil supply	7, 8
Technical data	8 11
Representation in the system network	12
Block diagram/controller function block	13
Electrical connections, assignment	14
LED displays	15
Characteristic curves	16 26
Dimensions	27 30
Accessories	31, 32
Project planning and maintenance instructions	32
Further information	32

WL



2/32 **4WRLF** | Directional control valve

Ordering code

01	02	03	04	05	06	07	80		09		10	11	12	13		14	15	16	17	18	
4	WRL	F							4X	/_				00	/	24		D9		*	
)1	4 main	ports																			4
)2	Directio	nal co	ontrol	valve,	pilot-c	perat	ed														WRL
03	With int	egrate	ed field	dbus																	F
04	Size 10																				10
	Size 16																				16
	Size 25																				25
	Size 27																				27
yml	ools																				
05	Possible	e versi	ions se	ee pag	ge 4																
06	d flow at		ır pres	sure c	differe	ntial (5 bar	per co	ontrol	edge)											
06	60 l/mii		v symh	nol F	F1- W	'6- W8	3- V a	nd V1	-)												60
	100 l/m		, 3yiii 6	, ot L,	_ , , ,,	0,110	, , u	110 7 1	,												100 ♦
	- Size 1																				100 1
	200 l/m		ılv svm	bol W	/6- and	W8-)															200 ♦
	250 l/m						and Q	3)													250 ♦
	- Size 2				· · ·																
	350 l/m	in (on	ıly sym	bol W	/6- and	1 W8-)	1)														350 ♦
	400 l/m	in (on	ıly sym	bol E	, E1-, \	/, V1-	and Q	3)													400 ♦
	- Size 2																				
	430 l/m	in (on	ıly sym	bol W	/6- and	d W8-)	1)														430 ♦
	600 l/m	in (on	ıly sym	bol E,	, E1-, \	/, V1-	and Q	3)													600 ♦
low	characte	ristic																			
07	Linear																				L ¢
	Linear v	vith fi	ne con	trol ra	ange (d	onlv N	G10:	other	sizes c	n rea	uest)										Р
	Progres																				M
08	Withou	t over	lan iun	nn (or	nlv svn	nhols	V V/1-	and C)3)												No code
00	With ov									/e· on	lv svm	hols F	F F1-	W6- 1	W/8-)						J
09	Compoi	nent s	eries 4	10 4	19 (40	49:	unch	anged	instal	lation	and r	nount	ing di	mensio	ons)						4X
eal	material	(obse	rve co	mpati	ibility	of sea	ls witl	h hydr	aulic f	luid u	sed, s	ee pa	ge 10))							
10	NBR sea	als																			M ¢
	FKM sea	als																			V
Pilot	oil flow																				
11	Externa	l nilot	oil su	nnly (extern	al nilo	ıt oil r	eturn													XY ¢
	Internal																				PY
	Internal	-																			PT ♦
	Externa																			+	XT
						at pito	. 011 11	CCUIII													Α1
	wich pla																				
12	Withou			lve																	10 code
		habit off value (condition plate value 174)ME C F1CC 2V/FC24 III and data short 22102)				14/1															

Bosch Rexroth AG, RE 29293, edition: 2022-05

With shut-off valve (sandwich plate valve "Z4WE 6 E166-3X/EG24...", see data sheet 23193)



Directional control valve | **4WRLF** 3/32

Ordering code

01	02	03	04	05	06	07	80		09		10	11	12	13		14	15	16	17	18
4	WRL	F						l –	4X	/				00	/	24		D9		*

13	Without internal pressure sensors	00
14	Supply voltage 24 V	24

Ethernet interface

15	EtherNET/IP	E
	PROFINET RT	N
	Sercos	s
	EtherCAT (CANopen profile)	Т
	VARAN	V

Connector

16	Voltage supply, enable acknowledgment	D9
----	---------------------------------------	----

Pressure sensor interface


	Sure SellSof Interface	
17	Without interface	0
	Analog interface for a maximum of 3 external pressure sensors (0 10 V)	5
18	Further details in the plain text	*

¹⁾ Higher rated flow upon request

Notice: ♦ = Preferred type




Symbols



With symbol E1-, V1- and W8-:

 $P \rightarrow A: \boldsymbol{q}_{V \text{ max}}$ $B \rightarrow T: \boldsymbol{q}_{V}/2$ $P \rightarrow B: \boldsymbol{q}_{V}/2$ $A \rightarrow T: \boldsymbol{q}_{V \text{ max}}$

Notice: ♦ = Preferred type



5/32



Directional control valve | 4WRLF

Function

General

The pilot-operated **IFB Multi-Ethernet** valve (Integrated **F**ield**b**us) is a digital directional control valve with integrated fieldbus.

The following operating modes are possible:

- ▶ Standard:
 - Valve direct control
 - Flow control
- ▶ Version "5" (with external pressure sensors):
 - Pressure/force control
 - Active damping
 - Alternating control (flow pressure/force);
 pQ function (flow-controlled)
- ► Command value presetting is done via the Ethernet interface (X7E1 or X7E2)
- ► The feedback information of the actual value signals to the higher-level control is provided via the Ethernet interface (X7E1 or X7E2)
- ► The controller parameters are set via the Ethernet interface (X7E1 or X7E2)

Set-up

The directional control valve with IFB Multi-Ethernet electronics mainly consists of:


- Pilot control valve (1) with control spool and sleeve in servo quality
- Main stage (2) with centering springs and position feedback
- ► Integrated fieldbus (3) with:
 - connector, voltage supply, safety shut-down (XH1)
 - Ethernet interfaces (X7E1, X7E2)
 - analog sensor interfaces (X2N)
 - interface for the position transducer of the main stage (X8A)

Function

The integrated electronics (OBE) compare the specified command value to the position actual value of the control spool of the main stage. In case of a control deviation, the control solenoid of the pilot control valve is activated and its control spool is adjusted.

The flow which is activated via the control cross-sections at the pilot control valve leads to an adjustment of the control spool of the main valve. The stroke/control cross-section of the main valve is regulated proportionally to the command value. In case of a command value presetting of 0%, the electronics adjust the control spool of the main valve to central position.

The pilot oil supply in the pilot control valve is either internal via port P or external via port X. The feedback can be internal via port T or external via port Y to the tank.



1) Only version "5"



Function

Symbol V and V1-

The control spool of the main valve is not in a safe position after the release is switched off. The enable acknowledgment (pin C) is not set. If the supply voltage fails or in case of cable break, the integrated electronics will de-energize the control solenoid, the pilot control spool will move to the fail-safe position and will unload the pilot oil chambers of the main valve. Operated by the spring, the control spool of the main valve will move to the offset position (approx. $6\% P \rightarrow B/A \rightarrow T$).

Symbol E., W. and Q3-

If the control spool of the main valve is in the covered spring-centered central position, the enable acknowledgment (pin C) is set. If the control spool of the main valve leaves the covered spring-centered central position or the release is set, the enable acknowledgment expires. If the supply voltage fails or in case of cable break, the integrated electronics will de-energize the control solenoid, the pilot control spool will move to the fail-safe position and will unload the pilot oil chambers of the main valve. The control spool of the main valve assumes the covered spring-centered central position.

Safety function

Thanks to the control solenoid (enable pin D, low signal) at the connector (XH1), shut-off is enabled. The control spool of the valve is in spring-centered central position after shut-off (see notes).

Enable acknowledgment pin C for solenoid B is "high". By connection of the control solenoid (enable pin D, high signal), the valve can be regulated in both directions by command value presetting.

Enable acknowledgment pin C for solenoid B is "low". The integrated control electronics (OBE) of the valve enables the additional shut-off of a channel according to EN 13849-1in both directions (depending on the symbol, the valve can be considered as safely shut-off). For this purpose, a suitable control system must be provided to perform the plausibility check between the direction-dependent valve signals "enable input" and "enable acknowledgment" (diagnosis signal fed back by the valve) and react in an error case. When using symbol V and V1-, the valve cannot be used in a safety-relevant manner according to EN 13849-1.

Monitoring

The digital control electronics enable comprehensive monitoring functions/error detection including:

- ▶ Undervoltage
- Communication error
- Cable break for analog sensor inputs
- ► Monitoring of the microcontroller (watchdog)
- ► Temperature of the integrated electronics

IndraWorks DS PC program

To implement the project planning task and to parameterize the valves, the user may use the IndraWorks DS engineering tool (see accessories):

- ► Project planning
- ► Parameterization
- ► Commissioning
- Diagnosis
- ► Comfortable administration of all data on a PC
- ▶ PC operating systems: Windows 7-10

Motice:

► Symbol V and V1-:

Pilot-operated 4/3 directional control valves are only functional in the active control loop and do not have a locking basic position when deactivated. Consequently, "external check valves" are required in many applications and must be taken into account regarding the switch-on/switch-off order. While the electrical supply voltage is being switched off, the drive may be accelerated for a short time in functional direction $P \rightarrow B$.


- ➤ Symbol E. and W.:
 Pilot-operated 4/3 directional control valves
 - with positive overlap are functional in controlled or regulated axes. The overlap in the de-energized state is approx. 20% of the control spool stroke. While the release is being switched off, the drive may be accelerated for a short time in functional direction $P \rightarrow B$ (see operating instructions 29391-B).
- 4/3 directional control valves do not have a leakage-free basic locking when deactivated. Leakage must be considered when designing the drive.
- ▶ Valve type 4WRLF can be used as shut-off element cat. 3 or 4 (up to PL e according to EN 13849-1). For both categories, an additional shut-off element is required to achieve a two-channel shut-off. For further information on the safety application, see operating instructions 29391-B.


7/32





Directional control valve | 4WRLF

Pilot oil supply (schematic illustration)









- Plug screw M6 according to DIN 906, wrench size 3pilot oil return
- 2 Plug screw M6 according to DIN 906, wrench size 3pilot oil supply
- Plug screw M12 x 1.5 according to DIN 906, wrench size 6

 pilot oil supply
- 6 Housing cover main stage (position transducer side)

Pilot oil supply

external: **2, 3** closed internal: **2, 3** open

Pilot oil return

external: 1 closed internal: 1 open

Further explanations on page 8.



Pilot oil supply

Version "XY" External pilot oil supply External pilot oil return

In this version, the pilot oil is supplied from a separate control circuit (external).

The pilot oil return is not directed into channel T of the main valve but is separately directed to the tank via port Y (external).

Version "PY" Internal pilot oil supply External pilot oil return

With this version, the pilot oil is supplied from channel P of the main valve (internal).

The pilot oil return is not directed into channel T of the main valve but is separately directed to the tank via port Y (external).

In the subplate, port X is to be closed.

Version "PT"

Internal pilot oil supply Internal pilot oil return

With this version, the pilot oil is supplied from channel P of the main valve (internal).

The pilot oil is directly returned to channel T of the main valve (internal).

In the subplate, ports X and Y are to be closed.

Version "XT" External pilot oil supply Internal pilot oil return

In this version, the pilot oil is supplied from a separate control circuit (external).

The pilot oil is directly returned to channel T of the main valve (internal).

In the subplate, port Y is to be closed.

Technical data

(For applications outside these values, please consult us!)

General									
Size		NG	10	16	25	27			
Type of connection			Subplate mounting						
Porting pattern			ISO 4401 -05-05-0-05	ISO 4401 -07-07-0-05	ISO 4401 -08-08-0-05	ISO 4401 -08-08-0-05			
Weight		kg	9	12	19	21			
Installation position			any						
Ambient temperature rai	nge	°C	-20 +60						
Storage temperature ran	ge	°C	+5 +40						
Maximum storage time	years	instructions 07600-B)							
Maximum relative humid	%	95							
Protection class accordi	Protection class according to EN 60529				IP65 (if suitable and correctly mounted mating connectors are used)				
Maximum surface tempe	rature	°C	120 (individual operation)						
MTTF _D value according	► Hydraulic (category 1)	years	75 (for further details, see operating instructions 29391-B)						
to EN ISO 13849	► Hydraulic and electric (category 3 and 4, without power supply unit)	years	70 (for further details, see operating instructions 29391-B)						
Sine test according to D	IN EN 60068-2-6		10 2000 Hz /	maximum of 10	g / 10 cycles / 3	3 axes			
Noise test according to I	DIN EN 60068-2-64		20 2000 Hz / 10 g _{RMS} / 30 g peak / 30 min. / 3 axes						
Transport shock accordi	ng to DIN EN 60068-2-27		15 g / 11 ms / 3 axes						
Conformity	► CE according to EMC directive 20 tested according to	014/30/EU,	EN 61000-6-2 and EN 61000-6-3						
	► RoHS directive		2011/65/EU 1)						

¹⁾ The product fulfills the substance requirements of the RoHS directive 2011/65/EU.

9/32



Directional control valve | 4WRLF

Technical data

(For applications outside these values, please consult us!)

Hydraulic									
Size		NG	10	16	25	27			
Maximum operating	▶ Ports A, B, P								
pressure	- External pilot oil supply	bar		350		270			
	– Internal pilot oil supply	bar			270				
	► Port X	bar	280			270			
	▶ Ports T, Y	bar		250		210			
Hydraulic fluid			see table page	10					
Hydraulic fluid temperati	ure range (flown-through)	°C	-20 +70						
Viscosity range	► Recommended	mm²/s	30 45						
	► Maximum admissible	mm²/s	20 380						
`	gree of contamination of the ss class according to ISO 4406 (c)		Class 18/16/13	2)					
Rated flow (Δp = 5 bar p	er control edge) ³⁾	l/min	60/100	60/100 200/250 350/400 4					
Maximum flow		l/min	300	800	1250	1850			
Leakage flow	▶ Symbol E, E1-								
(inlet pressure 100 bar)	- Main valve	l/min	0.06	0.13	0.17				
	- Main valve + pilot control valve	l/min	0.14	0.28	0.42				
	► Symbol W6-, W8-								
	- Main valve	l/min	0.12	0.26	0.35				
	- Main valve + pilot control valve	l/min	0.2	0.41 0.6					
Minimum pilot pressure	(pilot control valve)	bar	10						
Pilot flow ⁴⁾	► Symbol E, W	l/min	2.4	3.5		7.5			
	► Symbol V. Q3-	l/min	4.5	11.5	22				

2) The cleanliness classes specified for the components must be adhered to in hydraulic systems. Effective filtration prevents faults and at the same time increases the life cycle of the

³⁾ Flow for deviating Δp (per control edge):

$$q_x = q_{Vnom} \times \sqrt{\frac{\Delta p_x}{5}}$$

4) At port X and Y with stepped input signal from 0 ... 100% (100 bar)



Technical data

(For applications outside these values, please consult us!)

Hydraulic fluid	·	Classification	Suitable sealing materials	Standards	Data sheet
Mineral oils	,	HL, HLP, HLPD, HVLP, HVLPD	NBR, FKM	DIN 51524	90220
Bio-degradable	► Insoluble in water	HETG	FKM	ISO 15380	
		HEES	FKM	130 13360	90221
	► Soluble in water	HEPG	FKM	ISO 15380	
Flame-resistant	► Water-free	HFDU (glycol base)	FKM		
		HFDU (ester base)	FKM	ISO 12922	90222
		HFDR	FKM		
	► Containing water	HFC (Fuchs: Hydrotherm 46M, Renosafe 500; Petrofer: Ultra Safe 620; Houghton: Safe 620;	NBR	ISO 12922	90223
		Union: Carbide HP5046)			

Important information on hydraulic fluids:

- ► For further information and data on the use of other hydraulic fluids, please refer to the data sheets above or contact us.
- ► There may be limitations regarding the technical valve data (temperature, pressure range, life cycle, maintenance intervals, etc.).
- ► The ignition temperature of the hydraulic fluid used must be 50 K higher than the maximum surface temperature.
- ▶ Bio-degradable and flame-resistant containing water:

 If components with galvanic zinc coating (e.g. version "J3" or "J5") or parts containing zinc are used, small amounts of dissolved zinc may get into the hydraulic system and cause accelerated aging of the hydraulic fluid. Zinc soap may form as a chemical reaction product, which may clog filters, nozzles and solenoid valves particularly in connection with local heat input.

► Flame-resistant – containing water:

- Due to the increased cavitation tendency with HFC hydraulic fluids, the life cycle of the component may be reduced by up to 30% as compared to the use with mineral oil HLP. In order to reduce the cavitation effect, it is recommended – if possible specific to the installation – backing up the return flow pressure in ports T to approx. 20% of the pressure differential at the component.
- Dependent on the hydraulic fluid used, the maximum ambient and hydraulic fluid temperature must not exceed 50 °C.
 In order to reduce the heat input into the component, the command value profile is to be adjusted for proportional and high-response valves.

Static/dynamic					·					
Size		NG	10	16	25	27				
Hysteresis		%	< 0.1							
Range of inversion	%	< 0.08								
Response sensitivity	< 0.05									
Manufacturing tolerance q	≤ 10									
Temperature drift (temper	Zero shift < 0.25									
Zero point calibration		%	±1 (ex works)							
Step response time (for 0 100% at X = 100 bar)	► Symbols E, E1-, W6-, W8-	ms	40	60	60	60				
Switch-off behavior (after electric shut-off)	► Symbols E, E1-, W6-, W8-		Pilot control valve in fail-safe position, main valve moves to overlapped spring-centered central position							
	► Symbol V, V1-	► Symbol V, V1-			Pilot control valve in fail-safe position, main valve moves to spring-centered "offset position" (approx. 6%, P→B/A→T)					
	► Symbol Q3			ve in fail-safe po: "offset position"						



Directional control valve | 4WRLF 11/32

Technical data

(For applications outside these values, please consult us!)

Electrical, integrated elect	tronics (OBE)		
Supply voltage 5; 6)	► Nominal value	VDC	24
	► Minimum	VDC	18
	► Maximum	VDC	36
	► Maximum residual ripple	Vpp	2.5 (comply with the absolute supply voltage limit values)
	► Maximum power consumption	W	40
	► Fuse protection, external	Α	4, time-lag
Current consumption	► Maximum ⁷⁾	А	2.5
	► Impulse current	А	4
Relative duty cycle time acc	cording to VDE 0580	%	S1 (continuous operation)
Functional ground and scre	ening		see connector pin assignment (CE-compliant installation)
			page 14
Booting time		S	< 15
Switching input (enable)	► Quantity		1
XH1	► Low level range	V	-3 5
	► High-level range		15 U B
	► Maximum current consumption at high level	mA	< 1
Switching output	► Quantity		1
(enable acknowledgment)	► Low level range		0 3
XH1	► High-level range	V	15 U B
	Current carrying capacity	mA	50 (short-circuit-proof)
	► Inductive load admissible		No
Analog sensor X2N	► Quantity (voltage inputs)		3 8)
	► Supply voltage	V	24 (corresponding to supply voltage applied to XH2)
	► Maximum supply current	mA	50
	► AD resolution	bit	12
	► Voltage inputs		
	 Measurement range 	V	0 10
	- Input resistance	kΩ	100 +10%

⁵⁾ Supply voltage is used directly for sensor connection X8M (no internal voltage limitation)


⁶⁾ Voltage limit values must be observed directly at the connector of the valve (observe line length and cable cross-section!)

⁷⁾ The maximum current consumption will increase when using the sensor inputs or the switching output according to the external load

⁸⁾ Only version "5"




Representation in the system network (version "5")





Directional control valve | 4WRLF 13/32

Block diagram/controller function block






Electrical connections, assignment

Connector pin assignment XH1, 6-pole + PE according to DIN 43563


Pin	Assignment of interface D9
Α	24 VDC supply voltage 1)
В	GND
С	Enable acknowledgment 24 VDC (I_{max} 50 mA) ²⁾ (high \geq 15 V; low < 2 V)
D	Enable input 24 VDC (high ≥ 15 V; low < 2 V)
E	not used
F	not used
PE	Functional ground (connected directly to metal housing)



- $^{1)}\,$ A load increases the current consumption on pin A
- ²⁾ Enable acknowledgment is issued only if the valve has safely switched off according to EN 13849-1, see operating instructions 29391-B.


Connector pin assignment for Ethernet interface "X7E1" and "X7E2" (coding D), M12, 4-pole, socket

Pin	Assignment
1	TxD +
2	RxD +
3	TxD -
4	RxD -
5	not used



Analog configurable sensor interface, port "X2N" (coding A), M12, 5-pole, socket

Pin	Assignment				
1	+24 V voltage output				
2	Analog sensor input 2 (0 10 V)				
3	GND				
4	Analog sensor input 4 (0 10 V)				
5	Analog sensor input 3 (0 10 V)				





Motice:


- ▶ Reference potential for all signals: GND
- ► We recommend connecting the shields on both sides via the metal housings of the plug-in connectors. Using connector pins will affect the effectiveness of the shielding effect. Internal screens are not required.



Directional control valve | 4WRLF 15/32

LED displays

LED	Interface	Sercos	EtherNET/IP	EtherCAT	PROFINET RT	VARAN
MS	Electronics	Module status	Module status	Module status	Module status	Module status
NS	module	S	Network status and others			
L1	X7E1	Link and others	Link and others	Link/activity	Link and others	Link and others
S1	X/EI	Activity and others	Activity and others	not used	Activity and others	Active and others
L2	X7E2	Link and others	Link and others	Link/activity	Link and others	not used
S2	A/EZ	Activity and others	Activity and others	not used	Activity and others	not used
PWR	XH1	Power	Power	Power	Power	Power



Displays of the status LEDs

Power LED (LED PWR)	Display status	
Off	No voltage supply	
Green	Operation	
Module status LED (LED MS)	Display status	
Off	No voltage supply	
Green-red, flashing	Initialization	
Green, flashing	Drive ready for operation	
Green	Drive active	
Orange, flashing	Warning	
Red, flashing	Error	
Green, rapidly flashing	Firmware must be loaded	
Link LED (LED L1)	Display status	
Permanently lit	Cable plugged in, connection established	
Activity LED (LED S1)	Display status	
Flashing	Data sent/received	

Notice:


- ► For the connection to the M12 sockets, we recommend using self-locking mating connectors
- ▶ The MS module status LED relates to the electronics module
- ► The NS network status LED indicates the status of the control communication, see application description 30338-FK
- ► LEDs L1, S1, L2 and S2 relate to interfaces "X7E1" and "X7E2"
- ► For a detailed description of the diagnosis LEDs, please refer to the functional description Rexroth HydraulicDrive HDx.
- Function is only available after start-up of the electronics.




Characteristic curves: Flow characteristic "L" and "P" (measured with HLP46, ϑ_{oil} = 40 ±5 °C)

Flow/signal function - Version "L"

Symbol V, V1-




Symbols E, E1-, W6-, W8-




Flow/signal function - Version "P"

Symbol V, V1-



Symbols E, E1-, W6-, W8-





1) Step compensation (opening at 5%)





Directional control valve | 4WRLF 17/32

Characteristic curves: Flow characteristic "M" (measured with HLP46, ϑ_{oil} = 40 ±5 °C)













Characteristic curves

(measured with HLP46, ϑ_{oil} = 40 ±5 °C)

Pressure amplification








Directional control valve | 4WRLF 19/32

Characteristic curves: Size 10 (measured with HLP46, θ_{oil} = 40 ±5 °C)


Transition function with stepped electric input signals

Symbols V and Q3-



- ▶ Pilot control valve, port X = 100 bar
- ► Main valve, port P = 10 bar

Frequency response



Signal ±1%
Signal ±5%


_____ Signal ±25%

Signal ±100%



Characteristic curves: Size 10 (valid for HLP46, ϑ_{oil} = 40 ±5 °C)

Flow/load function (with maximum valve opening; tolerance ±10%)



- 1 Maximum admissible flow
- 2 Recommended flow (flow velocity 30 m/s)



Directional control valve | 4WRLF 21/32

Characteristic curves: Size 16 (measured with HLP46, ϑ_{oil} = 40 ±5 °C)


Transition function with stepped electric input signals

Symbol V Signal change in % 100 0 - 100 - 0 75 0 - 75 - 0Stroke in % → 50 0 - 50 - 0 25 0 - 25 - 00 - 10 - 0 10 0 20 40 60 80 90 40 80 90

Time in ms →

- ▶ Pilot control valve, port X = 100 bar
- ► Main valve, port P = 10 bar

Frequency response



Signal ±1%
Signal ±5%

Signal ±25%


Signal ±100%



Characteristic curves: Size 16

(measured with HLP46, 9_{oil} = 40 ±5 °C)

Flow/load function (with maximum valve opening; tolerance ±10%)




- 1 Maximum admissible flow
- 2 Recommended flow limitation (flow velocity 30 m/s)



Directional control valve | 4WRLF 23/32


Characteristic curves: Size 25 (measured with HLP46, ϑ_{oil} = 40 ±5 °C)

Transition function with stepped electric input signals



- ▶ Pilot control valve, port X = 100 bar
- ► Main valve, port P = 10 bar

Frequency response



Signal ±1%
Signal ±5%


Signal ±25% Signal ±100%



Characteristic curves: Size 25

(measured with HLP46, 9oil = 40 ±5 °C)

Flow/load function (with maximum valve opening; tolerance ±10%)




- 1 Maximum admissible flow
- 2 Recommended flow limitation (flow velocity 30 m/s)



Directional control valve | 4WRLF 25/32


Characteristic curves: Size 27 (measured with HLP46, ϑ_{oil} = 40 ±5 °C)

Transition function with stepped electric input signals



- ▶ Pilot control valve, port X = 100 bar
- ► Main valve, port P = 10 bar

Frequency response



Signal ±5%

_____ Signal ±25%


Signal ±100%



Characteristic curves: Size 27

(measured with HLP46, ϑ_{oil} = 40 ±5 °C)

Flow/load function (with maximum valve opening; tolerance ±10%)




- Pressure differential in bar \rightarrow
- 1 Maximum admissible flow
- 2 Recommended flow limitation (flow velocity 30 m/s)



Directional control valve | 4WRLF 27/32

Dimensions: Size 10 (dimensions in mm)




For item explanations, valve mounting screws and subplates, see page 30.


Motice:


The dimensions are nominal dimensions which are subject to



Dimensions: Size 16 (dimensions in mm)







For item explanations, valve mounting screws and subplates, see page 30.


Motice

The dimensions are nominal dimensions which are subject to tolerances.



Directional control valve | 4WRLF 29/32

Dimensions: Sizes 25 and 27 (dimensions in mm)



NG	L1	L2	L3	L4	L5	L6	L7	H1	H2	Н3	(H3)	H4	B1	B2
25	15	19	364	191	187	260	281	46	126	286	336	195	118	120
27	15	20.5	371	198	190	264	284	50	140	300	350	200	120	124

For item explanations, valve mounting screws and subplates, see page 30.

Notice:

The dimensions are nominal dimensions which are subject to



Dimensions

- 1 Pilot control valve
- 2 Main valve
- 3 Integrated electronics (OBE)
- 4 Inductive position transducer (main valve)
- 5 Name plate
- **6** Identical seal rings for ports P, A, B, T; Identical seal rings for ports X, Y
- **7** Space required for removing the mating connector
- 8 Mating connectors, separate order, see page 31 and data sheet 08006.
- 9 Locking pin
- **10.1** Machined valve contact surface, porting pattern according to ISO 4401-05-05-0-05
- 10.2 Machined valve contact surface, porting pattern according to ISO 4401-07-07-0-05 Deviating from the standard: ports P, A, B, T – Ø20 mm Minimum screw-in depth:
 - ▶ Ferrous metal: 1.5 x Ø
 - ▶ Non-ferrous metal: 2.0 x Ø

- **10.3** Machined valve contact surface, porting pattern according to ISO 4401-08-08-0-05 Deviating from the standard:
 - ▶ NG25: Ports X, Y Ø14 mm
 - ► NG27: Ports P, A, B, T Ø32 mm Minimum screw-in depth:
 - ► Ferrous metal: 1.5 x Ø
 - ▶ Non-ferrous metal: 2.0 x Ø
- 11 Dimension () with version "WL"
- **12** Shut-off valve, optional (sandwich plate valve "Z4WE 6 E166-3X/EG24...", see data sheet 23193)
- 13 Port X2N (only version "5")

Valve mounting screws (separate order)

Size	Quantity	Hexagon socket head cap screws	Material number
10	4	ISO 4762 - M6 x 45 - 10.9-CM-Fe-ZnNi-5-Cn-T0-H-B	R913043777
		Tightening torque M_A = 13.5 Nm ±10%	
	or		
	4	ISO 4762 - M6 x 45 - 10.9	Not included in the Rexroth
		Tightening torque M _A = 15.5 Nm ±10%	delivery range
16	2	ISO 4762 - M6 x 60 - 10.9-CM-Fe-ZnNi-5-Cn-T0-H-B	R913043410
		Tightening torque M _A = 12.2 Nm ±10%	
	4	ISO 4762 - M10 x 60 - 10.9-CM-Fe-ZnNi-5-Cn-T0-H-B	R913014770
		Tightening torque M _A = 58 Nm ±20%	
	or		
	2	ISO 4762 - M6 x 60 - 10.9	Not included in the Rexroth
		Tightening torque M _A = 15.5 Nm ±10%	delivery range
	4	ISO 4762 - M10 x 60 - 10.9	
		Tightening torque M _A = 75 Nm ±20%	
25, 27	6	ISO 4762 - M12 x 60 - 10.9-CM-Fe-ZnNi-5-Cn-T0-H-B	R913015613
		Tightening torque M _A = 100 Nm ±20%	
	or		
	6	ISO 4762- M12 x 60 - 10.9	Not included in the Rexroth
		Tightening torque M _A = 130 Nm ±20%	delivery range

Notice:

The tightening torque of the hexagon socket head cap screws refers to the maximum operating pressure.

Subplates (separate order) with porting pattern according to ISO 4401, see data sheet 45100.



Directional control valve | 4WRLF 31/32

Accessories (separate order)

Mating connectors and cable sets

Port	Designation	Version	Short designation	Material number	Data sheet
XH1	Mating connector;	Straight, metal	7PZ31M	R900223890	08006
	for valves with round connector,	Straight, plastic	7PZ31K	R900021267	
	6-pole + PE	Angled, plastic	_	R900217845	-
	Cable sets;	Plastic, 3.0 m	7P Z31 BF6	R901420483	08006
	for valves with round connector,	Plastic, 5.0 m]	R901420491	
	6-pole + PE	Plastic, 10.0 m		R901420496	
		Plastic, 20.0 m	-	R901448068	_
X7E1, X7E2	Cable set; shielded, 4-pole, D coding	Straight connector M12, on straight connector M12, line cross-section 0.25 mm², CAT 5e, length freely selectable (= xx.x)	_	R911172111 1)	_
	Cable set; shielded, 4-pole	Straight connector M12, on straight connector RJ45, line cross-section 0.25 mm², CAT 5e, length freely selectable (= xx.x)	_	R911172135 ²⁾	_
X2N	Cable set; shielded, 5-pole, for connecting Rexroth pressure sensors, type HM20, A coding	PUR/PVC, straight connector M12, on straight socket M12, line cross-section 0.34 mm², 0.6 m	-	R901111709	-
		PUR/PVC, straight connector M12, on straight socket M12, line cross-section 0.34 mm², 1.0 m	-	R901111712	-
		PUR/PVC, straight connector M12, on straight socket M12, line cross-section 0.34 mm², 2.0 m	-	R901111713	-
	Cable set; shielded, 5-pole, A coding	Straight connector M12, on free line end, line cross-section 0.34 mm², 1.5 m	-	R901111752	-
		Straight connector M12, on free line end, line cross-section 0.34 mm², 3.0 m	-	R901111754	-
		Straight connector M12, on free line end, line cross-section 0.34 mm², 5.0 m	-	R901111756	-
		Straight connector M12, on free line end, line cross-section 0.34 mm², 10.0 m	-	R913005147	-

 $^{^{1)}}$ Additional indication of type designation RKB0040/xx.x

Notice:

- ► Tighten the M12 connector with a manual torque wrench by 1 Nm.
- ▶ Self-locking M12 cables must be used.
- ▶ It must be ensured that cables are secured without radial force.
- ▶ All cables connected to "XH1", "X7E1" and "X7E2" must be bundled in a wire harness after 20 cm the latest. The wire harness must be fixed after further 20 ... 30 cm. Make sure that there is no relative motion between the fixation and the valve.
- ▶ Before the fixation point, there must not be any cable loops.
- ► In general, the information on installation provided by the cable manufacturers must be observed.
- ► Respectively, the cable of "X2N" (if used) is also fixed as described above.
- ▶ For further information, see operating instructions 29391-B

 $^{^{2)}}$ Additional indication of type designation RKB0044/xx.x



Accessories (separate order)

Protective cap

Protective cap M12	Version	Material number
		R901075563

Parameterization

The following is required for th	Material number/download	
1 Commissioning software	IndraWorks, Indraworks D, Indraworks DS	www.boschrexroth.com/IAC
2 Connection cable, 3 m	Shielded, M12 on RJ45, length can be freely selected (= xx.x)	R911172135 (additional indication of type designation RKB0044/xx.x)

Project planning and maintenance instructions

- ► The supply voltage must be permanently connected; otherwise, bus communication is not possible.
- ► If electro-magnetic interference is to be expected, take appropriate measures for ensuring the function (depending on the application, e.g. shielding, filtration).
- ► The devices have been tested in the plant and are supplied with default settings.
- Only complete devices can be repaired. Repaired devices are returned with default settings. User-specific settings will not be applied. The machine end-user will have to retransfer the corresponding user parameters.

Further information

► High-response/proportional valve with Multi-Ethernet interface

► Operation fieldbus electronics (xx = software version):

- Functional description Rexroth HydraulicDrive HDx-20
- Parameter description Rexroth HydraulicDrive HDS-16, HDx-17 ... HDx-20
- Description of diagnosis Rexroth HydraulicDrive HDS-16, HDx-17 ... HDx-20
- Subplates
- ► Hydraulic fluids on mineral oil basis
- ► Environmentally compatible hydraulic fluids
- ► Flame-resistant, water-free hydraulic fluids
- ► Flame-resistant hydraulic fluids containing water
- ► Hydraulic valves for industrial applications
- ► General product information on hydraulic products
- ► Installation, commissioning and maintenance of servo valves and high-response valves
- ▶ Commissioning software and documentation on the Internet
- ► Information on available spare parts

Operating instructions 29391-B

- 30338-FK
- 30330-PA
- 30330-WA

Data sheet 45100

Data sheet 90220

Data sheet 90221

Data sheet 90222 Data sheet 90223

Operating instructions 07600-B

Data sheet 07008

Data sheet 07700