

YDAC INTERNATIONAL

Universal Charging and Testing Unit

FPU-1 For Bladder, Piston and Diaphragm

1. DESCRIPTION

1.1. FUNCTION

The charging and testing unit FPU-1 is used to charge accumulators with nitrogen or to check or to change the existing pre-charge pressure in accumulators. For this purpose the charging and testing unit is screwed onto the gas valve of the hydraulic accumulator and connected to a commercial nitrogen bottle via a flexible charging hose. If the nitrogen pressure is only to be checked or reduced, the charging hose does not need to be connected. The unit has a screw-type fitting with a built-in gauge, check valve and a spindle for opening the accumulator gas valve to control the pressure.

HYDAC piston and diaphragm accumulators can be charged and checked without the need for adaptors. Bladder accumulators, however, require an adaptor (A3 supplied as standard, see model code on page 2).

The FPU-1 must only be used for its intended purpose.



1.2. INTERVALS BETWEEN **CHECKING**

On the whole, nitrogen losses on HYDAC hydraulic accumulators are very low. However, a regular check of the gas pre-charge pressure is recommended to prevent the piston from hitting the cover plate or the bladder or diaphragm from becoming too deformed, if there is a drop in the pressure po.

The pre-charge pressure po as shown on the label or the accumulator body, must be reset after every new installation or repair and then checked at least once during the following week. If no nitrogen loss is detected, a further check should be made after approx. 4 months. If after this period no change in the pressure is found, a yearly check should be sufficient.

1.3. CONSTRUCTION

The HYDAC charging and testing unit for bladder, piston and diaphragm accumulators consists

- Valve body
- Spindle
- Check valve
- Release valve
- Gauge
- Charging hose
- A3 adaptor for bladder accumulators

1.4. ACCESSORIES

□ Gas safety valve with **intermediate piece** TUV set and lead sealed, it must be fitted between the hydraulic accumulator and the nitrogen bottle by means of the intermediate piece, if the gas pressure in the commercially available nitrogen bottle is higher than the max. permissible operating pressure of the hydraulic accumulator.

- Pressure reducer for setting the required pre-charge pressure between nitrogen bottle and
- accumulator.

 □ Protective case for storing the charging and testing unit and adaptors.

Different types of case are available, depending on customer requirement.

2. TECHNICAL SPECIFICATIONS

2.1. MODEL CODE (also order example)

Universal charging and testing unit -Gauge indication range 0 - 10 bar 0 - 145 psi 10 0 - 25 bar 0 - 363 psi 25 100 0 - 100 bar 0 - 1450 psi 0 - 250 bar 0 - 3626 psi 250 0 - 400 bar 0 - 5714 psi 400

FPU-1 250 F 2.5 G2 A1 K

Charging hose

F = for 200 bar nitrogen bottle with connection W24.32x1/14 (DIN 477, Part 1) FM = for 300 bar nitrogen bottle with connection M30x1.5 (DIN

477, Part 5 to April 2002)

FW = for 300 bar nitrogen bottle with connection W30x2 (DIN 477, Part 5 from April 2002)

A is supplied as standard)

Length of charging hose 2.5 m 2.5

4.0 m 4 Special lengths on request

Adaptor G for nitrogen bottles -

See table under point 10 (page 15)

Adaptor A

A1 = M16x1.5A2 = 5/8 - 18 UNF A3 = 7/8 - 14 UNF A4 = 7/8 - 14 UNF A5 = M8x1

A6 = G 3/4 AA7 = G 1/4

A8 = G 3/4

A9 = Vg 8A10 = 7/8 - 14 UNF

A11 = M16x2

D4 = 5/8 - 18 UNF(Part no. 366374) other adaptors on request

Protective case

Accessories (Please give full details when ordering.) Gas safety valve with intermediate piece (see point 5.3.). Pressure reducer (see point 5.1.) Adaptor for connector D (see point 4.1.). Wrench 14x15 (Part no. 1011065). Allen key SW6 (Part no. 1005164). Valve tool for gas valve (Part no. 616886). Torque wrench (Part no. 3136470)

2.2. WEIGHT

Standard model without case: approx. 1.4 kg Standard model with case:

approx. 3.0 kg

2.3. FPU-1 STANDARD MODELS 2.3.1 **Model without case**

Model code	Part no.
FPU-1-010F2.5A3	2114486
FPU-1-025F2.5A3	2114481
FPU-1-100F2.5A3	2114310
FPU-1-250F2.5A3	2114306
FPU-1-400F2.5A3	2115646
FPU-1-010F4A3	2115056
FPU-1-025F4A3	2116876
FPU-1-100F4A3	2115657
FPU-1-250F4A3	2114311
FPU-1-400F4A3	2119673

2.3.2 Model with case

Model code	Part no.
FPU-1-010F2.5A3K	2115365
FPU-1-025F2.5A3K	2114305
FPU-1-100F2.5A3K	2115314
FPU-1-250F2.5A3K	2114302
FPU-1-400F2.5A3K	2114307
FPU-1-010F4A3K	3013690
FPU-1-025F4A3K	2116738
FPU-1-100F4A3K	2114842
FPU-1-250F4A3K	2114303
FPU-1-400F4A3K	2114304

2.3.3 Model without case with G adaptor

Model code	Part no.
FPU-1-250F2.5G2A3	2120252
FPU-1-250F2.5G3A3	2115555
FPU-1-250F2.5G4A3	2124611
FPU-1-250F2.5G9A3	2114312
FPU-1-250F4G3A3	2123839
FPU-1-250F4G6A3	2117532
FPU-1-250F4G10A3	2119789
FPU-1-400F2.5G2A3	2115823
FPU-1-400F2.5G3A3	2121557
FPU-1-400F2.5G8A3	2115693

2.3.4 Model with case and G adaptor

2.3.4 WIOGEI WITH Case a	and G adaptor
Model code	Part no.
FPU-1-010F2.5G2A3K	2116766
FPU-1-010F2.5G3A3K	2127228
FPU-1-010F2.5G4A3K	2125524
FPU-1-010F2.5G6A3K 2	2115661
FPU-1-010F2.5G7A3K	2117851
FPU-1-010F2.5G8A3K	2117303
FPU-1-010F2.5G9A3K	2114482
FPU-1-010F2.5G10A3K	3008015
FPU-1-010F4G7A3K	2124450
FPU-1-025F2.5G2A3K	2114401
FPU-1-025F2.5G3A3K	2121210
FPU-1-025F2.5G4A3K 2	2115247
FPU-1-025F2.5G5A3K 3	3013724
FPU-1-025F2.5G8A3K 2	
FPU-1-025F2.5G9A3K 2	
FPU-1-025F2.5G10A3K	
FPU-1-025F4G9A3K	2119680
FPU-1-100F2.5G2A3K 2	
FPU-1-100F2.5G4A3K 2	
FPU-1-100F2.5G6A3K3	
FPU-1-100F2.5G9A3K	2119883
FPU-1-100F4G3A3K	2120359
FPU-1-250F2.5G2A3K 2	
FPU-1-250F2.5G3A3K 2	
FPU-1-250F2.5G4A3K	
FPU-1-250F2.5G5A3K 2	
FPU-1-250F2.5G6A3K	2115420
FPU-1-250F2.5G7A3K 2	
FPU-1-250F2.5G8A3K	2115216
FPU-1-250F2.5G9A3K	2115833
FPU-1-250F4G2A3K	2116743
FPU-1-250F4G3A3K 21	
FPU-1-250F4G4A3K	2128944
FPU-1-250F4G8A3K	2124860
FPU-1-250F4G9A3K	2116004
FPU-1-250F4G10A3K 2	125750
FPU-1-400F2.5G2A3K	2114605
FPU-1-400F2.5G3A3K 2	2115692
FPU-1-400F2.5G4A3K	2128360
FPU-1-400F2.5G5A3K 2	2124387
FPU-1-400F2.5G6A3K	2121984
FPU-1-400F2.5G8A3K	2116005
FPU-1-400F2.5G9A3K 2	2115757
FPU-1-400F4G2A3K	2122119
FPU-1-400F4G3A3K	2115656
FPU-1-400F4G7A3K	2124504
FPU-1-400F4G8A3K 21	19759
FPU-1-400F4G9A3K	2126309
FPU-1-400F4G10A3K	2116642
	<u> </u>

2.4. SPECIAL MODELS



For higher pressures, the following special models are available:

- ☐ FPS 600 for bladder accumulators up to 600 bar max. pre-charge pressure (see technical information 293715).
- ☐ FPK 600 for piston, diaphragm and SB800-1.5 accumulators up to 600 bar max. pre-charge pressure (see technical information 297248).
- ☐ FPH 800 for high pressure bladder accumulators up to 800 bar max. pre-charge pressure (see technical information 242948).

3.1. TAKING ACCOUNT OF THE TEMPERATURE EFFECT

In order that the recommended pre-charge pressures are maintained even at relatively high operating temperatures, the pre-charge pressure po charge for charging and testing a cold accumulator must be selected as follows:

po charge = po Pre-charge temp. + 273 Operating temp. + 273 Pre-charge temperature [°C] Operating temperature [°C]

3.2. PREPARATION

Prior to each testing, topping-up or re-charging of nitrogen, the accumulator must be isolated from the pressurised system by means of a shut-off valve and the fluid released.

Unscrew the protective caps S and H (only on bladder accumulators). Remove the O-ring O on bladder accumulators. Slightly loosen the internal hexagon screw P on piston and diaphragm accumulators by means of an Allen key SW 6, DIN 911 (approx. ½ turn). Place FPU-1 onto the accumulator and screw connector D by hand onto accumulator gas valve. At the same time, ensure that the release B of the FPU-1 is closed. Turn charging unit to a position where the gauge can be easily read

3.3. TESTING

On bladder accumulators


(FPU-1 with A3 or other suitable adaptor) open valve by turning

spindle A clockwise.
On piston and diaphragm
accumulators (FPU-1)
open valve V by turning the
internal hexagon screw
anticlockwise with spindle


When the needle of the gauge begins to move, give the spindle another complete turn. The gauge now shows the charging pressure in the accumulator. The check valve C prevents any escape of nitrogen.

3.4. REDUCING THE PRE-CHARGE PRESSURE


Carefully open release B. The nitrogen escapes into the atmosphere.




Charging and testing unit FPU-1 for piston and diaphragm accumulators



Gas valve for piston and diaphragm accumulators



Charging and testing unit for bladder accumulators with adaptor A3




Gas valve for bladder accumulators

3.5. INCREASING PRE-CHARGE PRESSURE

Only use nitrogen for charging accumulators Never use oxygen! Danger of explosion! If the gas pressure in the nitrogen bottle is higher than the max. operating pressure of the accumulator, a gas pressure reducer must be fitted.

- Connect the flexible charging hose to the pressure reducer on the nitrogen bottle by means of the connector G1. For nitrogen bottles from other countries the appropriate adaptor is required (see page 15). Connect connector M of the charging hose to the check valve C of the charging and testing unit FPU-1. Open the shut-off valve on the nitrogen bottle, and slowly release nitrogen into the accumulator. Wait until approximately 1 bar has been reached before opening the shutoff valve of the nitrogen bottle further to enable faster charging.
- ☐ Interrupt the charging process from time to time and check the pre-charge pressure reached. Repeat this process until the required gas pre-charge pressure is achieved. After temperature equalisation has taken place, re-check the pre-charge pressure and adjust if necessary. If the pressure is too high, it can be lowered via the pressure release B of the FPU-1.
- ☐ If the required gas pre-charge pressure has been reached, turn the spindle anticlockwise to close the gas valve on bladder accumulators. On piston or diaphragm accumulators close the internal hexagon screw P by turning the spindle clockwise. Discharge the charging and testing unit FPU-1 via the pressure release and remove it by loosening the connector. On bladder accumulators, unscrew the adaptor and replace the O-ring O. On piston and diaphragm accumulators, tighten the internal hexagon screw P with Allen key [20 Nm].
- Check for leakages on the accumulator gas valve using a leak detector spray.
- Screw on cap nut H (only on bladder accumulators) and valve protection cap S onto the gas valve of the accumulator and tighten.

3.6. FPU-1 WITH ACCESSORIES



3.7. WARNING

Nitrogen and operating fluid can escape when filling or testing the accumulator due to a faulty, i.e. leaking, bladder, diaphragm or piston seals.


Caution!

Risk to health in the case of aggressive fluids! (special charging and testing unit available on request)


- The check valve C must not be removed. The valve has a safety function for the whole charging and testing unit.
- During charging, by a compressor or nitrogen charging system connected upstream, continuous operation can lead to unacceptable increases in temperature.
- Rest periods must therefore be incorporated into the charging procedure and the FPU-1 must be allowed to cool down.

4. DIMENSIONS


4.1. CHARGING AND TESTING UNIT FPU-1 WITH ADAPTOR FOR HYDAC ACCUMULATORS




4.2. CHARGING HOSE ${\bf F}$ (200 bar nitrogen bottle - connection to DIN 477, part 1)



4.3. CHARGING HOSE **FM** (300 bar nitrogen bottle - connection to DIN 477, part 5 to April 2002)




4.4. CHARGING HOSE **FW** (300 bar nitrogen bottle - connection to DIN 477, Part 5 from April 2002)




Charging hoses are suitable for the respective published maximum permissible operating pressures and 10,000 charging processes. (HYDAC charging hoses comply with the EC machine directive and with DIN EN 982 and DIN EN 853 to 857).

4 ADAPTORS A1 TO A12 The universality of the FPU-1 is guaranteed because as well as HYDAC piston and diaphragm accumulators, bladder accumulators can also be charged and tested using the A3 adaptor.


By using additional adaptors other makes of accumulator can also be charged and tested.




A1 (Part no. 361619)




A2 (Part no. 361605)




A3 (Part no. 291533)




A4 (Part no. 291536)




A5 (Part no. 291531)




A6 (Part no. 2108819)




A7 (Part no. 2110629)




A8 (Part no. 2124524)




A9 (Part no. 2128638)




A10 (Part no. 2128849)




A11 (Part no. 3018210)




A12 (Part no. 3203185)




G 2 (Part no. 236376)




G 3 (Part no. 2103421)




G 4 (Part no. 236374)




G 5 (Part no. 236373)




G 6 (Part no. 2103423)




G 7 (Part no. 236377)




G 8 (Part no. 2103425)




G 9 (Part no. 241168)




G 10 (Part no. 2103427)



G 11 (Part no. 3018678)




G 12 (Part no. 3195556)



E 3.501.9/04.08

5. ACCESSORIES


5.1. PRESSURE REDUCER FOR 200 BAR NITROGEN BOTTLES (Connection W24.32x1/14 - DIN 477, Part 1)



Bottle pressure [bar]	Reduces pressure to between [bar]	Part no.
200	0- 20	635409
200	0-100	635411
200	0-200	635412


Weight: 2.3 kg

5.2. PRESSURE REDUCER FOR 300 BAR NITROGEN BOTTLES (Connection W30x2 - DIN 477, Part 5 from April 2002)



Bottle pressure [bar]	Reduces pressure to between [bar]	Connection H	Part no.
300	0 - 20	W24.32x1/14	6004020
300	0-100	W24.32x1/14	6004021
300	0-200	W24.32x1/14	6004022

Weight: 2.3 kg



5.3.1 Model code (also ordering example) GSV6 - 10 - CE0034.ENISO4126-1.6.G. 195. 330 Gas safety valve Component code Flow rate Q in kg/h (see table, point 5.3.2) Pressure setting p in bar

5.3.2 Types of GSV6 Part no. Q [kg/h] p [bar] 15 30 3123965 20 40 28 50 35 Others on request 60 40 70 3124030 5.3.5 **Module category**3124031 IV to PED 45 80 50 90 97/23/EC3 24032 Module B + D (EC prototype 100 58 test)3124033 module G (EC individual test) 3124034 65 110 on request 70 120 130 3124035 75 3124036 83 140 150 3124037 88 160 3124038 95 170 3124039 100 105 180 3124040 190 3124041 110 118 200 125 210 130 220 3124044

(see table, point 5.3.2)

5.3.3 Type of construction Direct-acting gas safety valve nominal width 6 mm

3123966 5.3.4 **Design** 3123967 PED 97/23/EC. 3124028 EN ISO41236-1, EN 13445-6 3124029

> 5.3.6 Materials stainless steel, closing element with flexible seat

5.3.7 Operating pressure range 30 to 370 bar

3124042 5.3.8 Temperature range 3124043 -20 to +80 °C

> 5.3.9 Operating fluid Nitrogen (N₂)

5.3.10 Mounting position optional

5.1324048/eight 3124050 1.1

3124045

3124047

195 330 3124055 200 340 3124056 205 350 3124057 360

230

250

270

280

240 3124046

260 3124048

290 3124051 300 3124052

310 3124053

320 3124054

210 3153706 216 370 3143015 others on request

> 350 bar = additional price for EC individual testing

135

140

148

155

160

165

170


178 185

190

E 3.501.9/04.08

5.4. INTERMEDIATE PIECE GSV6-10-CE


Intermediate piece for fitting the gas safety valve GSV6 between the 200 bar nitrogen bottle and the charging and testing unit FPU-1 (Part no. 242558)




6. CHARGING AND TESTING BLOCK F + P

The HYDAC charging and testing block F+P is used to charge and test back-up type hydraulic accumulators. It has connections for the charging and testing unit FPU-1 and for pressure gauges. As a safety function, a gas safety valve GSV6 can be fitted. In addition it allows the back-up nitrogen bottles to be shut off from the hydraulic accumulator.


6.1. BACK-UP TYPE HYDRAULIC ACCUMULATOR WITH CHARGING AND TESTING BLOCK



6.2. CHARGING AND TESTING BLOCK DN 16



6.3. CHARGING AND TESTING BLOCK DN 32



7. SPARE PARTS

tem	Quantity	Designation		Part no.
1	1	O-ring 6x1		601 032
2	1	Seal ring		612 730
3	1	Pressure	0 - 10 bar	635 139
-		gauge	0 - 25 bar	635 140
			0 - 100 bar	635 141
			0 - 250 bar	635 142
			0 - 400 bar	635 143
5	1	O-ring 15x2		601 049
6	1	Seal ring		601 456
7	1	O-ring 11x2		601 043
8	1	O-ring 9x2		601 040
9	1	O-ring 11x2.5		603 681
10	1	O-ring 5.7x1.	9	6004009
		Seal kit FPU	J-1	2117669
ADAP	TOR A			
		Seal kit Adap	otor A1 - A12	3269153
GAS S	SAFETY VAL	VE GSV6-10-CI	<u> </u>	
Item	Quantity	Designation		Part no.
11		Seal ring	21.54x28.58x2.47	6018877
		to the HYDAC on the contract of the contract o	charging and testing block, O-	ring 18x2.5
raiti	10. 601 057)	must be fitted.		
INTER	RMEDIATE P	IECE GSV6-10-	-CE	
 Item	Quantity	Designation		Part no.
12	2	O-ring	20x2.5	601 058
13	1	Seal ring	20x11.5x2	614 706
14	 1	Seal ring	14x8.5x2	612 735
			mediate piece	2117287
CHAR	GING AND T	ESTING BLOC	:K	
		Seal kit F+P	DN 16	2115776
		Seal kit F+P	DN 32	2112088

8. NITROGEN CHARGING UNIT



HYDAC nitrogen charging units facilitate fast and cost-effective filling or testing of the required gas pre-charge pressure in bladder, diaphragm or piston accumulators. They guarantee optimum use of commercially available nitrogen bottles up to a residual pressure of 20 bar and a maximum accumulator pressure of 350 bar. Portable, mobile and stationary types of N2 Server are available. For further details and technical specifications, see HYDAC brochure "Nitrogen Charging Unit N2 Server", no.: E 2.201.

9. NOTE

The information in this brochure relates to the operating conditions and applications described. For applications or operating conditions not described, please contact the relevant technical department.

Subject to technical modifications.

Country	G1 ₁₎	Tig2 G3 G4 G5 2			Type / Part r 2103423 G7	10. Gb 236377	G8	G9	G10	G11	G12	
	()	236376	2103421	236374	236373			2103425	241168	2103427	3018678	3195556
lbania				2000.	2000.0			2.00.20		0	00.00.0	0.0000
lgeria rgentina			0									
ustralia ustria												
ahamas	Ш											
ahrain angladesh												
arbados												
elgium olivia												
otswana												
razil Julgaria												
urma			-									
anada hile												
hina												
olombia osta Rica												
yprus												
zech Republic enmark												
jibouti			0									
ominican Republic cuador												
gypt thiopia												
iji												
nland rance												
abon												
ambia ermany												
hana	п											
reat Britain reece												
uatemala												
uinea uyana												
onduras												
ong Kong ungary												
dia												
donesia an												
aq												
eland rael												
aly												
ory Coast amaica												
apan						0						
ordan enya												
orea												
uwait ebanon												
ibya Ialawi		00										
lalaysia												
lalta lauritius			00									
exico												
orocco ozambique												
etherlands			<u> </u>									
ew Zealand igeria												
orway												
man akistan												
araguay												
eru hilippines												
oland												
ortugal uerto Rico												
atar												
omania ussia												
audi Arabia		В										
ngapore outh Africa												
oain ri Lanka												
ıdan												
ırinam vaziland												
veden												
vitzerland												
ria iwan												
nzania												
nailand inidad/Tobago										0		
ınisia		В										
ırkey nited Arab Emirates												
uguay												
SA enezuela												
etnam												
igoslavia, the former2)												1

^{□=} suggestion ₁) = already fitted to hose ₂) = Bosnia-Herzegovina, Croatia, Macedonia, Slowenia