



Sales partner

HC7-U miniBOOSTER



HC7- U versions: 6 different intensification factors

 $P_{\text{\tiny IN}}$: 20 – 207 bar (inlet pressure)

P_H: 2000 bar maximum (outlet pressure)

P_{RETURN}: As low as possible (return pressure to tank)

 P_{outlet} : $P_{\text{H}} = (P_{\text{IN}} - P_{\text{Return}}) x \text{ i (intensification)}$

Mounting: Inline tube

Accessories: Pilot- operated dump valve incorporated

B model = with dump valve

G model = direct proportionally controlled

Material certificate on request.

Description

The HC7- U is a very compact high-pressure unit capable of delivering pressure up to 2,000 bar, weighing only 1.5 kg. It is ideal for use in portable applications like on power packs. Oil from the cylinder will be released directly via T- port to the tank, with a minimum back pressure.

The HC7- U raises supplied pressure to a higher outlet pressure and automatically compensates for consumption of oil to maintain the high pressure. Adjustment of the outlet pressure is carried out by varying the supplied pressure. With the choice of different high-pressure adapters, a variety of threads can be obtained from the M22x1.5 thread in the HP port. Higher pressure is available on request.

Flow rates

Intensification factor i	Max. outlet flow I/ min	Max. inlet flow I/ min
5.0	1.6	14.0
6.6	1.3	13.0
9.0	0.9	13.0
10.3	0.8	12.0
13.0	0.6	12.0
20.0	0.3	12.0

Functions

The basic operation is illustrated in the function diagram. Oil is fed through the directional valve CV to the IN port, flowing freely through the check valves KV1, KV2 to the high- pressure side H. In this condition, maximum flow through the booster is achieved, giving a fast-forward, function

When pump pressure is reached on the high- pressure side H, valves KV1, KV2 and DV will close. The end pressure will be achieved by the oscillating pump unit OP. The unit will automatically stall when end pressure on the high- pressure side H is reached. If a pressure drop on the high- pressure side exists due to consumption or leakage, the OP valve will automatically operate to maintain the end pressure.





(+44 (0)1204 699959


enquiries@hyquip.co.uk www.hyquip.co.uk



Function diagram



Function diagram 7-113-01



Dimensions



Dimension drawing 7-130-01

Connection types

Connection	Т	IN/R
1	1/4" BSP	1/4" BSP
2	9/16 - 18 UNF	7/16-20" UNF

Max. tightening torque BSP

	IN/R
	1/4" BSP
with steel washer	4.0 da/ Nm
with aluminium washer	3.0 da/ Nm
with cutting edge	4.0 da/ Nm

Max. tightening torque UNF

	IN/R
	7/16-20" UNF
with o- ring	2.0 da/ Nm





(+44 (0)1204 699 959

enquiries@hyquip.co.uk www.hyquip.co.uk



Sales partner

High- pressure adapters

Ordering code	Male connection 1	Connection 2	Max. pressure
7-432	M22 x 1.5	9/16-18 UNF	2,600 bar
7-433	M22 x 1.5	1/4" BSP	2,600 bar
7-434	M22 x 1.5	Plug	2,600 bar
7-435	M22 x 1.5	1/4" BSP	800 bar
7-439	M22 x 1.5	9/16-18 UNF	1,380 bar
7-445	M22 x 1.5	1/4" BSP male	2,600 bar
7-446	M22 x 1.5	M22 x 1.5	2,600 bar
7-447	M22 x 1.5	7/16-20 UNF	1,380 bar

High- pressure adapter ordering codes and specifications can be seen from the table in the PDF- file below:



High- pressure adapters: 7-900-05

Fluids and materials

Please see: General specifications

Ordering an HC7- U

Ordering example of an HC7- U with i = 13.0, H1 M22 x 1.5 and H2 9/16-18 UNF,

DV incorporated and BSP connections: HC7 - 13.0 - B - 12U

Please note!

High- pressure adapter ordering code – see table

Model	Intensification, i	Dump valve	Dump valve		Connections
HC7- U	your selection	your select	your selection		see table below
	see flow rate table	A = (no) / A	A = (no) / A model		
		B = (yes) / I	B = (yes) / B model		
		G = (proport	ional) / G model		
	Ordering code	IN, R	H1	H2	H3
	HC711U	1/4" BSP	M22 x 1.5	-	_
	HC721U	7/16-20 UNF	M22 x 1.5	-	-
	HC712U	1/4" BSP	M22 x 1.5	9/16-18 UNF	-
	HC722U	7/16-20 UNF	M22 x 1.5	9/16-18 UNF	-
	HC713U	1/4" BSP	M22 x 1.5	9/16-18 UNF	9/16-18 UNF
	HC723U	7/16-20 UNF	M22 x 1.5	9/16-18 UNF	9/16-18 UNF

